

NA NB Outer Tie Rod End Installation Instructions 89-05 Mazda MX-5 Miata

Have a Mazda FSM (Factory Service Manual) on hand for torque specs. Digital versions can be found on eBay.

Install supplied load spreading washer under castle nut as shown

42.2-56.9 Nm

4.31-5.8 kgf-m

31.2-41.9 ft-lbs

Install cotter pin bend tail to secure



Follow us [YouTube](#) /949racingsupermiata [Facebook](#) /supermiata [Instagram](#) @supermiata

info@949Racing.com 949-716-3111

www.SUPERMIATA.com

